

I - APPLIANCE DESCRIPTION

A	Pusher
B	Funnel
C	Lid
D	Filter
E	Pulp container
F	Anti-drip spout
G	Body of appliance
H	Side safety lock clips
I	ON/OFF switch
J	Speed selector
K	Cones (2) (according to model)
L	Citrus press sieve (according to model)
M	3 glasses (according to model)
N	Glass holder accessory (according to model)
O	Cleaning brush
P	Cord storage

II - BEFORE FIRST USE

Completely release the side safety lock clips **(H)**. Remove the pusher **(A)**, lid **(C)**, filter **(D)**, pulp container **(E)**, glass-holder accessory **(N)** and glasses **(M)**.

Clean all the accessories in warm water with washing-up liquid, dry and then re-assemble the appliance.

III - USING THE JUICER

You can use the juicer to get juice from practically all fruits and vegetables, whether they are hard or soft. However, you will not manage to extract juice from bananas, coco-nuts, avocado pears, blackberries, figs, aubergines and so on.

III A – Starting up the centrifuge

1. Lock the side safety clips **(H)** and lid **(C)** securely;
2. Cut the fruit or vegetables into pieces and remove stones.
3. Place a glass under the spout to collect the juice.
4. Make certain that the spout is in the low position **(fig 1)**.
5. Plug in the appliance.
6. Start up the juicer by pressing the switch **(I)**.
7. Select the speed to correspond to the fruit (see table below) using button **(J)**.
8. Remove the pusher and introduce the fruit or vegetables in pieces through the funnel.
You must introduce fruit and vegetables with the motor running.
9. Use the pusher to push the food down but do not force. Do not use any other utensil. Above all, **DO NOT USE YOUR FINGERS** to push the food. The juice will flow into the glass through the spout while the pulp will accumulate in the pulp container.
10. Once your glass is full, stop the appliance and push the spout up into the raised position again (fig 2).
11. Once the tank looks full or the flow of juice slows down, empty the pulp container using the handle of the brush **(O)** and clean the filter with the brush if necessary.
12. When you have finished using the appliance, you are advised to clean the accessories quickly using the brush **(O)** so that food does not dry onto them. Apart from the body of the appliance, you can put all these accessories in the dishwasher (top basket).

Cleaning – Foods which stain plastics

Over time the strong coloured natural juices from food such as carrots and beetroot may stain the plastic parts of your appliance – this is normal. These parts may be cleaned by soaking them in mild bleach (non abrasive) straight after use.

13. Some hints.

Ingredients	Approximate number of fruits before you need to empty the pulp container	Recommended speed	Approximate weight	Quantity of juice obtained (*) (1 glass = about 25cl)
Carrots	10	V2	1 kg	500ml
Cucumbers	2	V2	1 kg	600ml
Apples	5	V2	1.2 kg	700ml
Pears	5	V2	1,2 kg	750ml
Melons	1 à 2	V1	1.5 kg	900ml
Pineapples	2	V2	2 kg	1000ml
Grapes		V1	2 kg	1200ml
Green salad	2 à 3	V2	0.5 kg	250ml
Tomatoes	7	V1	1.5 kg	900ml
Celery	3	V2	1.5 kg	900ml

(*)The quality and quantity of the juice obtained will vary considerably according to the date of harvest and the variety of each vegetable or fruit. The quantities of juice shown above therefore provide only a rough guide.

III B – Practical hints using the juicer

1. Choose fresh, ripe fruit and vegetables.
2. Carefully wash the fruit and vegetables before cutting them and removing the stones.
3. Peel thick-skinned fruit.
4. The juicier the fruit (as with tomatoes) the slower the speed you should use (see table for information above).
5. If you prepare juice from grapes, quinces, bilberries or blackcurrant, you should clean the filter every time you press 1/2 kg.
6. If you juice over-ripe fruit, you will obtain a fairly thick liquid, the filter will tend to get clogged up and you should then clean it more regularly. You will also have to empty the pulp container more or less often according to the quality of the fruit or vegetables processed.
7. **Important:** all juices should be drunk immediately. When they come into contact with the air, they oxidise very quickly and this may impair their taste and colour. Apple and pear juice quickly takes on a brown colour. Add a few drops of lemon to prevent the juice going brown too quickly.

IV - USING THE CITRUS PRESS ACCESSORY (according to model)

1. Release the side safety lock clips **(H)**.
2. Remove the lid **(C)** and filter **(D)**.
3. Position the citrus press grid **(L)** on the pulp container **(E)** with the appropriate cone **(K)** according to the size of the fruit.
4. Secure the citrus press grid **(L)** to the pulp container **(E)** using the safety lock clips **(H)**.
5. Plug in the appliance.
6. Make certain that the spout is in the low position **(fig 1)**
7. Select the slowest speed **(J)** and set the switch **(I)** to "On".
8. Press the citrus fruit.

V - SAFETY INSTRUCTIONS

- Do not leave the appliance in the reach of unsupervised children. Children should not use the appliance.
- Let rotating parts come to a complete stop before opening the appliance.
- Always use the pusher to guide food down the funnel. Never introduce your fingers, a fork, knife, spatula or any other object.
- Do not allow long hair, scarves, ties, etc. to dangle over accessories when in operation.
- Unplug your appliance as soon as you stop using it.
- Do not put the motor unit in water or any other liquid. Do not rinse it.
- Do not exceed the maximum quantities or operation times shown in the recipes table.
- Do not use the appliance if the rotating filter is damaged.
- The appliance complies with technical regulations and standards in force.
- This appliance is designed to work only with AC current. Before using check that the mains supply corresponds to that shown on the rating plate of the appliance.
- Do not use the appliance or place it on a hot surface or near a flame (gas cooker).
- Use the appliance on a stable work surface away from water.
- The appliance must be unplugged:
 - * if there are any signs that it is not working normally
 - * before cleaning or servicing
 - * after use
- Never unplug the appliance by pulling on the cord.
- Only use an extension cord if you have already checked that it is in good working order and has a suitable rating.
- Household appliances should not be used if they have been dropped.
- If the power supply cord is damaged, it must be replaced by the manufacturer, their after-sales service or a person with similar qualification to avoid any hazards.
- This product has been designed for domestic use only. Any commercial use, inappropriate use or failure to comply with the instructions, the manufacturer accepts no responsibility and the guarantee will not apply.
- The product rating plate with its characteristics is underneath the appliance.

If you have any product problems or queries, please contact our Customer Relations Team first for expert help and advice:

HELPLINE:

0845 602 1454 - UK

(01) 4751947 - Ireland

or consult our website - www.tefal.com